
Copyright Affirm

The Company reserved all right.

The content of the product specification consulted relevant laws and industry benchmarks. If you are caught in some problems, when using our products. Please consult sales people, or call our customer service hot-line, or send a letter to us.

The Company reserves the right to modify product, product type and specifications, and other files without notify the user.

Our company has patent right, copyright and other intellectual property on this product and its software. Anyone can not direct or indirect copy, manufacture, machining and use the product and its part without authorization.

Our company has copyright of the instruction manual. It can not be amended, copied and use any part without permission.

CHAPTER 1 PARA PATTREN	1
1.1 ENTER WAY	1
1.2 TRUEFALSEBAG	2
1.3 MOONTTOOTHBAG	3
CHAPTER 2 OPEN-BAG DESIGN	7
2.1 ENTRY MODE	7
2.2 TEMPLATE INTRODUCTION	8
2.3 BAG TYPE PARAMETER DESCRIPTION	10
2.3.1 A-Sew Lenght	10
2.3.2 B-Sewing Width	10
2.3.3 C-Upper left cutting distance in the X direction	11
2.3.4 C0-Distance from cutting midpoint in the X direction	11
2.3.5 C1-Upper right cutting distance in the X direction	11
2.3.6 C2-Lower left cutting distance in the X direction	11
2.3.7 C3-X-directional distance for cutting in the lower right corner	12
2.3.8 D-Upper left cutting Y-direction distance	12
2.3.9 D0-Y-distance of cutting midpoint	12
2.3.10 D1-Y-direction distance of upper right cutting	13
2.3.11 D2-Bottom left cutting Y-direction distance	13
2.3.12 D3-Y-direction cutting distance at the bottom right	13
2.3.13 E-Starting position of E-cutting	13
2.3.14 FL-Empty Left	14
2.3.15 FR-code to right distance (right)	14
2.3.16 V1-Y compensation distance (left)	14
2.3.17 V2-Y compensation distance (left)	15
2.3.18 V3-Y compensation distance (right)	15
2.3.19 G-Staggered distance	16
2.3.20 H-Bias distance	16
2.3.21 H-MH/H Speed Offset Len	17
2.3.22 V3-Y Compensate Above Right	17
2.3.23 V1- Laser Point To Ring Hight	18
2.3.24 V2- Two Ring Len	18
2.4 OPERATION DEMONSTRATION	22
CHAPTER 3 SETTING FUNCTIONS RELATED TO PATTERN MAKING STYLES	24
3.1 SEWING INTERFACE	25
3.2 MENU MODE	26
3.3 XY SETP MOTOR TEST	26
3.4 CHANGING NEEDLE THREAD TENSION	26
3.5 WIND MODE	27
3.6 SINGLE STEPPING TEST	27
3.7 OPENING-BAG DESIGN	27
3.8 MODIFICATION MODE	28
3.9 UP COUNTER SET	31
3.10 LINE COUNTER SET	31
CHAPTER 4 DEVICE DETECT	32
4.1 LED DETECTION	33
4.2 PANEL DETECTION	34
4.3 INPUT DETECTION	35
4.4 OUTPUT DETECTION	35
4.5 XY STEP MOTOR TEST	36
4.6 SERVO TEST	36
4.7 SERVO ANGLE DETECTION	37
4.8 CONTINOUS RUN DETETION	37
CHAPTER 5 SYSTEM UPGRADE AND FUNCTION SETTINGS	38
5.1 SYSTEM UPGRADE	38
5.2 FUNCTION MODE	39
CHAPTER 6 RESERVED PARA	40
6.1 RESERVED PARAMETER OPERATION	40
6.2 PARAMETER INTRODUCTION	41

Chapter 1 Para Pattern




1.1 Enter Way

1、Click on the menu on the interface.




2、Enter the menu mode interface,click"Para Version".



3、Choice "TureFalseBag" or "MoonToothBag",click Enter.




1.2 TrueFalseBag



Function explanation:

Order	Function	Content
A	Type	Single/Double Single: Usually fake pockets, zipper bags Double: Usually real pockets, stitching goes around twice
B	Laser	Select laser style
C	LineMark	Select thread pattern settings
D	Reset	Enter parameter directory settings interface
E	Pattern preview	Enter parameter directory settings interface
F	Laser Middle Set	laser intermediate stitching shape, laser intermediate up/down offset, etc
G	Sewing stitch length	Set stitching needle pitch
H	Length value	Click the number to modify the interval distance value

1.3 MoonToothBag



Function explanation:


Number	Function	Content
A	Type	Select the number of laser operations
B	Laser	Select the style the laser
C	LineMark	Select the ststich pattern for the loop
D	Reset	Enter the parameter directory setting interface
E	Pattern preview	Enter the pattern preview interface
F	Sewing stitch length	Set the stitching needle pitch

Example number explain:


Number	Content
A	Represents the lenght of the pocket
B	Represents the width of the pocket
C	Distance between the laser and the wide edge of the fabric
D	Distance between the laser and the upper/lower edges of the fabric
E	Cutting start postion
G	Offset distance of the cutting point
H	Medium/high speed/high speed offset distance
V	Distance between the laser and the long edge of the fabrce

Operation demonstration:

1、 Select a laser for one time.



2、 Set the sewing needle size to 3.0,click ok.



3. Select laser type as type 3. Click to preview.



4. Enter the graphical preview interface. Click to exit.



5. Click the translation button to enter the next page.



6. You can set graphic data, such as setting the number of head reverse sewing times to 2 and the number of needle start reverse sewing times to 2. Click confirm.



7. Click on Settings to adjust the XY position values of the laser start point and sewing start point.




8. Click OK.



9. Set the name and number, click OK.



10. The figure is shown on the right.























Chapter 2 Open-bag Design




2.1 Entry Mode

<p>1. Click "Menu" on the main interface</p>	<p>The screenshot shows the main interface of the software. A red circle highlights the 'Menu' button located in the bottom right corner of the main panel.</p>
<p>2. Enter the menu mode interface and click "Laser mode"</p>	<p>The screenshot shows the menu mode interface. A red circle highlights the 'Laser mode' button, which is represented by a bag icon, located in the bottom row of the menu options.</p>
<p>3. Enter the "Open-Bag Design" interface</p>	<p>This screenshot is identical to the one at the top of the page, showing the 'open-bag design' interface with various bag design options.</p>

2.2 Template Introduction

formwork drawing	name	formwork drawing	name
	Second Sew Have Noose		Second Sew No Noose
	Four Sides Sew (Left)		Four Sides Sew (Right)
	Three Sides Sew (up)		Three sides Sew (Right)
	Three sides Sew (Left)		Seamless seal Glue (Semi-Circle)
	Once Sew No Noose		Once Sew Have Noose
	Straight Cut Once Sew Have Noose		Straight Cut Twice Sew Have Noose
	Circle Once Sew		Circle Twice Sew
	Common Mode Dark-line		Cotton Clothes Twice Sew Have knot
	Cotton Clothes Twice Sew Have knot		Cotton Clothes Once Sew Have knot
	Cotton Clothes Once Sew Haven' t knot		Secondary Sew Three Sides Sew (up)




Main interface function description:

Serial	Function	Content
A	Display Diagram	Pattern data annotation , area letters correspond to letters in G area
B	Pattern Zero Point Setting	Adjust pattern zero point XY position values
C	Laser Middle Setting	Set laser middle cutting shape, laser middle up/down offset, etc.
D	Restore Default	Restore default values
E	Preview	Enter marking graphic
F	Pattern Parameter Area	Value setting

2.3 Bag Type Parameter Description

By modifying the parameters related to the bag type, the entire bag type can be adjusted as needed. The parameters of different bag types are different.

The following is a schematic diagram of the parameters of Second Sew Have Noose.




numb	Parameter
A	Sewing length
B	Sewing width
C	X-direction distance
C0	X-direction distance
C1	X-direction distance
C2	X-direction distance
C3	X-direction distance
D	Y-direction distance
D0	Y-direction distance
D1	Y-direction distance
D2	Y-direction distance
D3	Y-direction distance
E	Cutting start position
FL	Empty Left
FR	Code To Right Len
V1	Y Compensate Above Left
V2	Y Compensate Above Left
V3	Y Compensate Above Right

Below is a brief introduction to the definition and setting effects of bag type parameter.

2.3.1 A-Sew Length


Definition: The horizontal distance of bag type sewing thread, with a numerical range of 0.0-999.9mm
The following figure shows the effect of secondary sewing without a knot when the sewing length is 50 and 100.



2.3.2 B-Sewing Width

Definition: The longitudinal distance between the upper and lower sewing threads of a bag type, with a numerical range of 0.0-999.9mm.


The following figure shows the effect of secondary sewing without a knot when the sewing width is 20 and 30.



2.3.3 C-Upper left cutting distance in the X direction

Definition:The horizontal distance from the upper-left cutting point to the sewing line, with a numerical range of 0.0-9999 mm.


illustration:The figure below shows the effect diagram when horizontal distance for the upper-left cutting point in second stitching without a knot is set to 20 and 10, respectively.



2.3.4 C0-Distance from cutting midpoint in the X direction

Definition: The horizontal length from the cutting midpoint to the left and right sewing threads, with a numerical range of 0.0-999.9mm.


The picture shows the effect of cutting the middle point in the X direction at distances of 4 and 6 without a knot during secondary sewing.



2.3.5 C1-Upper right cutting distance in the X direction

Definition: The horizontal length from the upper right cutting point to the right sewing thread, with a numerical range of 0.0-999.9mm.


The following image shows the effect when the distance in the X direction of the cutting point on the upper right of the secondary sewing without a knot is 5 and 10.




2.3.6 C2-Lower left cutting distance in the X direction

Definition: The horizontal length from the lower left cutting point to the left sewing thread, with a numerical range of 0.0-999.9mm.

The following image shows the effect when cutting in the X direction at distances of 5 and 10 from the bottom left without a knot during secondary sewing.



Cutting distance in the lower left X direction=5




Cut the lower left X direction distance=10


2.3.7 C3-X-directional distance for cutting in the lower right corner

Definition: The horizontal length from the lower right cutting point to the right sewing thread, with a numerical range of 0.0-999.9mm.

The following image shows the effect when cutting in the X direction at distances of 5 and 10 from the bottom right without a knot during secondary sewing.



Cutting in the lower right X direction with a distance of 5




Cutting in the lower right X direction with a distance of 10

2.3.8 D-Upper left cutting Y-direction distance

Definition: The longitudinal length of the sewing thread from the upper left cutting point to the top, with a numerical range of -999.9-999.9mm.

The following image shows the effect when cutting in the Y direction at distances of 2 and 4 in the upper left corner without a knot during secondary sewing.



Cutting in the upper left direction with a distance of 2 in the Y direction




Cutting in the upper left direction with a distance of 4 in the Y direction

2.3.9 D0-Y-distance of cutting midpoint

Definition: The longitudinal length of the sewing thread from the cutting midpoint to the upper and lower edges, with a numerical range of 0.0-999.9mm.

The following figure shows the effect of cutting the middle point in the Y direction at distances of 2 and 6 without a knot during secondary sewing.



Cutting the middle point with a distance of 2 in the Y direction




Cutting the middle point with a distance of 6 in the Y direction

2.3.10 D1-Y-direction distance of upper right cutting

Definition: The longitudinal length of the sewing thread from the upper right cutting point to the top, with a numerical range of 0.0-999.9mm.


The following image shows the effect when cutting in the Y direction at distances of 2 and 5 in the upper right corner without a knot during secondary sewing.



2.3.11 D2-Bottom left cutting Y-direction distance

Definition: The longitudinal length of the sewing thread from the lower left cutting point to the bottom, with a numerical range of 0.0-999.9mm.


The following image shows the effect when cutting in the Y direction at distances of 2 and 5 for the second sewing without a knot.



2.3.12 D3-Y-direction cutting distance at the bottom right

Definition: The longitudinal length of the sewing thread from the bottom right cutting point to the bottom, with a numerical range of 0.0-999.9mm.


The following image shows the effect when cutting the Y-direction at distances of 2 and 5 in the lower right corner without a knot during secondary sewing.




2.3.13 E-Starting position of E-cutting

Definition: The horizontal distance from the starting point of the cutting line to the starting points of the upper and lower sewing lines, with a numerical range of 0.0-999.9mm.

The following image shows the effect when the cutting start position is 11 and 30 for the second sewing without a knot.



Starting point of cutting centerline=11



Starting point of cutting centerline=30


2.3.14 FL-Empty Left

Definition: The horizontal distance between the empty feed distance and the left sewing thread, with a numerical range of 0.0-999.9mm.

The following figure shows the effect when the horizontal distance between the empty feed distance and the left sewing thread is 5 and 15 for the second sewing without a knot.



Empty delivery distance (left)=5




Air delivery distance (left)=15

2.3.15 FR-code to right distance (right)

Definition: The lateral distance from the code (side slip 2 lift) to the right, with a numerical range of 0.0-999.9mm.

The following figure shows the effect when the horizontal distance from the code to the right is 5 and 15 for the 'secondary sewing without knot'.



Distance from code to right (right)=5




Distance from code to right (right)=15


2.3.16 V1-Y compensation distance (left)

Definition: When sewing to the upper left corner, continue sewing downwards for a distance and then return, with a numerical range of 0.0-999.9mm.

The following figure shows the effect of Y compensation distance (left) at distances of 5 and 15 when there is no knot in the secondary sewing.



Y compensation distance (left)=5




Y compensation distance (left)=15

2.3.17 V2-Y compensation distance (left)

Definition: When sewing to the bottom left corner, continue sewing upwards for a distance and then return, with a numerical range of 0.0-999.9mm.


The following figure shows the effect when the Y compensation distance (left) is 5 and 15 for the second sewing without a knot.




2.3.18 V3-Y compensation distance (right)

Definition: When sewing to the bottom right corner, continue sewing upwards for a distance and then return, with a numerical range of 0.0-999.9mm.

The following figure shows the effect when the Y compensation distance (on the right) is 5 and 15 for the secondary sewing without a knot.



The following is a schematic diagram of the parameters for Four Sides Sew (Left).




numb	Parameter
A	Sewing length
B	Sewing width
C	X-direction distance
G	Staggered distance
C1	X-direction distance
C2	X-direction distance
C3	X-direction distance
D	X-direction distance
H	Bias distance
D1	Y-direction distance
D2	Y-direction distance
D3	Y-direction distance
E	Cutting starting position
FL	Empty delivery distance (left)
FR	Distance from code to right (right)
V1	Y compensation distance (left)
V2	Y compensation distance (left)
V3	Y compensation distance (right)

2.3.19 G-Staggered distance

Definition: The horizontal distance between two cutting points, with a numerical range of 0.0-999.9mm.


The following image shows the effect when the four sides are sewn (left) with a staggered distance of 4 and 8.




2.3.20 H-Bias distance

Definition: The lateral distance offset between the upper and lower sewing threads, with a numerical range of 0.0-999.9mm.

The following figure shows the effect of [four side sewing (left)] when the tilt distance is 10 and 15.



The following is a schematic diagram of the parameters for Three Sides Sew (up).




numb	Parameter
A	Sewing length
B	Sewing width
C2	X-direction distance
C3	X-direction distance
D2	Y-direction distance
D3	Y-direction distance
E	Cutting start position
G	Stagger distance
H	MH/H Speed Offset Len
V3	Y Compensate Above Right

2.3.21 H-MH/H Speed Offset Len

Definition: The lateral distance of medium to high speed/high-speed offset, with a numerical range of 0-100mm.


The following figure shows the effect when the high-speed/high-speed offset distance is 4 and 8 in the "Three Side Sewing (Top)".




2.3.22 V3-Y Compensate Above Right

Definition: The longitudinal distance under Y compensation distance (right), with a numerical range of 0-100mm.

The following figure shows the effect when the compensation distance is 5 and 10 respectively for the top three side sewing.



The figure is a schematic diagram of the parameters of Seamless seal Glue (Semi-Circle).




numb	Parameter
A	Sewing length
B	Sewing width
G	Laser end point offset Len
H	Laser point off Ring width
E	Sew end point offset Len
FR	Laser End Point To Right Len
V1	Laser Point To Ring Hight
V2	Two Ring Len

2.3.23 V1-Laser Point To Ring Hight

Definition: The height of the laser point from the ring, with a numerical range of 0.0-999.9mm.

The following figure shows the effect of seamless sealing (semi-circular) when the starting point of the cutting centerline is 10 and 18.




Laser point to ring height=10

Laser point to ring height=18

2.3.24 V2-Two Ring Len

Definition: The longitudinal distance between the laser ring and the sewing ring, with a numerical range of 0.0-999.9mm.


The following figure shows the effect of seamless sealing (semi-circular) when the distance between the two rings is 3 and 6.



Distance between two rings=3

Distance between two rings=6


The figure is a schematic diagram of the parameters for Circle Twice Sew.



number	Parameter
A	Sewing length
B	Sewing width
C	X-direction distance
FD	Code To Left Down Len
LD	Laser End Point To Left Len
RD	Laser End Point To Right Len
E	Cutting Start Position
FL	Code To Left Len
FR	Code To Right Len
V1	Y Compensate Above Left
V2	Y Compensate Above Left
V3	Y Compensate Above Right

2.3.25 LD-Laser End Point To Left Len

Definition: The lateral distance of the end point of the left laser, with a numerical range of 0-100mm. The following figure shows the effect of secondary sewing of a circle when the distance between the laser endpoint on the left end is 5 and 10.




Left end laser endpoint distance=5

Left end laser endpoint distance=10

2.3.26 RD-Laser End Point To Right Len


Definition: The lateral distance from the end point of the right laser, with a numerical range of 0-100mm. The following figure shows the effect of secondary sewing of a circle when the distance between the laser finish point on the right end is 5 and 10.



Right end laser endpoint distance=5

Right end laser endpoint distance=10


The figure is a schematic diagram of the parameters for Common Mode Dark-line.



numb	Parameter
A	Sewing length
B	Sewing width
C	X-direction distance
C1	X-direction distance
C2	X-direction distance
C3	X-direction distance
D	Y-direction distance
D1	Y-direction distance
D2	Y-direction distance
D3	Y-direction distance
E	Cutting start position
H	Start Stitch Offset Len (right)
FR	Code To Left Len
FD	Code To Left Down Len


2.3.27 FR-Code To Left Len

Definition: The horizontal distance from the code to the left (left), with a numerical range of 0-100mm. The following figure shows the effect of the 'Normal Mode Dark Line' code when the distance to the left (left) is 10 and 20.




2.3.28 FD-Code To Left Down Len

Definition: The horizontal distance from the code to the bottom left corner (bottom left), with a numerical range of 0-100mm. The following figure shows the effect of the 'Normal Mode Dark Line' code when the distance from the bottom left corner (bottom left) is 10 and 20.




The figure is a schematic diagram of the parameters for Cotton Clothes Twice Sew Have knot.



num	Parameter	numb	Parameter
A	Sewing length	D3	Y-direction
B	Sewing width	E	Cutting start
C	X-direction distance	FL	Code To left Len
C0	X-direction distance	FR	Code To Right Len
C1	X-direction distance	V1	Y Compensate Above Left
C2	X-direction distance	V2	Y Compensate Above Left
C3	X-direction distance	V3	Y Compensate Above Right
D	Y-direction distance	SL	sew point to left Len
D0	Y-direction distance	W	Sew width space(rightup)
D1	Y-direction distance		
D2	Y-direction distance	V	Sew width space(rightup)


2.3.29 SL-sew point to left Len (left)

Definition: The horizontal distance from the sewing point to the left end (left), with a numerical range of 0-100mm. The following image shows the effect when the distance from the sewing point to the left end (left) of the cotton jacket with a knot is 2.5 and 10, respectively.




2.3.30 W-Sew width space(rightup)

Definition: The horizontal distance of the sewing width interval (top right), with a numerical range of 0-100mm. The following image shows the effect when the starting point of the cutting line is 5 and 10 for the secondary sewing of cotton clothing with a knot.



2.3.31 V-Sew width space(rightup)

Definition: The longitudinal distance of the sewing height interval (top right), with a numerical range of 0-100mm. The following image shows the effect when the starting point of the cutting line is 2 and 6 for the secondary sewing of cotton clothing with a knot.



2.4 Operation Demonstration

1. Select the corresponding bag opening template.



2. Set corresponding values for needle spacing, length, width, etc. Use the page turning button to modify other data items.








3. Click the preview button to enter the graphic preview interface. Click to exit.




4. Click on Settings and adjust the XY position value of the pattern alignment point through the steering wheel.



	
<p>5. Click OK to save the pattern.</p>	
<p>6. Click OK.</p>	
<p>7. Set the name and number, click OK.</p>	
<p>8. The figure is shown on the right.</p>	

Chapter 3 Setting Functions Related to Pattern Making Styles




Main interface function description:

Serial	function	content
A	content	Display the current pattern
B	pattern	Adjust sewing speed
C	speed	Enter the Menu mode
D	menu	Enter the XY origin detection interface
E	XY origin detection	Return to origin function
F	Quick tool change	Enter the tension adjustment line interface
G	Winding mode	Enter the winding mode to set the winding core speed
H	home	Return to the origin
I	single stepping test	Enter the single step testing interface
J	Enter sewing	Enter the sewing interface
K	Processing Count	Set the processing count value
L	clean up	Quick Clear Key
M	Bottom line count	Set the baseline count value
N	Pattern number	Switching patterns
O	Shortcut Key - Bag Opening	Enter the quick printing interface for bag opening design,
P	Shortcut Key - Pattern	Enter pattern modification mode

3.1 Sewing Interface

Click the 'Enter Sewing' button on the main interface to enter the sewing interface. As shown in the following figure.



Function Description:

Serial	function	content
A	speed	Adjust sewing speed
B	Medium pressure foot	Lift presser foot /Lower presser foot
C	Medium pressure foot	Display press foot height numerically
D	menu	Enter menu mode
E	Needle machine	Raise needle/Lower needle
F	Large pressure plate	Lower press plate/Life press plate
G	Small pressure plate	Lower small press foot/Life height numerically
H	Head lifting and lowering	Raise needle/Lower needle
I	cutting	Perform material discharge action
J	home	Perform return to origin action
K	trim	Perform thread cutting action
L	pattern	Display current sewing pattern
M	Shortcut Key - Bag Opening	Enter quick pattern making interface for pocket design, set
N	Bottom line count	Set stitch count value
O	Shortcut Key - Pattern	Enter pattern modification mode
P	Set line tension	Entert thread tension tension adjustment interfac
Q	Exit sewing	Return to main interface P1

3.2 Menu Mode

Click the 'Menu' button on the main interface to enter menu mode.



3.3 XY Setp Motor Test

Click the "XY setp motor test" button on the main interface to enter the XY Origin Tset interface.



3.4 Changing Needle Thread Tension

Click the "Changing Needle Thread Tension" button on the main interface to enter the setting line tension interface.



2、Set the laser stitching shape to straight line
 The intermediate laser stitching shape can be set to three types: Straight line ,herringbone stitch, and S-shpaed



line

zig

yes


3、Select the laser type as Type2.




4、Select the stitch type as Type3.Click Preview




5、Enter the graphic preview interface
Click Exit.



6、Enter the graphic preview interface
Click Exit.



7、You can set graphic data, such as setting
the backstitch count 3 and starting
stitch count to 3. Click Confirm.



8、Click Setting, and use the directional
pad to adjust the pattern alignment to the
target XY position.




9、Click Confirm.



10、 Set the name and number, and click Confirm .



11、 The graphic is shown as in the right.



3.9 Up Counter Set

Click the [Up Counter Set] button on the main interface to enter the counter settings interface.



3.10 Line Counter Set

Click the [Line Counter Set] button on the main interface to enter the counter settings interface.



- Included:**
- 1.Production cunt current set value(total count) setting.
 - 2.Production count current value setting.
 - 3.Counter function on/off button.
 - 4.Clear current value button ,witch resets the current count to zero.
- Set Target Count:**In the settings area,input the requied target count value to ensure it meets production requiements.
- Click Confirm Button:**The system will start counting the oridution data during the production process.

Chapter 4 Device Detect



Interface Function Description:

1. Enter the Device Test Interface

Function Description: Users can enter the device test interface via the device test detection button in the menu.

2. Led Detection

Function Description: Start or stop the screen detection function and set the detection time.

3. Panel Detection

Function Description: Users can enter the touchscreen detection

4. Input Detection、 Output Detection

Function Description:

This function is used to detect the status of input and output signals to ensure the system receives correct signals.

Usage Steps:

- 1.1 Find the input and output signal detection button in the device test interface.
- 1.2 Click this button to start the input signal.
- 1.3 Observe the signal status displayed on the interface to confirm whether the signal is normal.

Function Description:

This function is used to detect the status of the input or output signal to ensure the system receives the correct signal.

Usage Steps:

- 1.1 Find the input signal test button in the device test interface.
- 1.2 Click the button start the input signal test.
- 1.3 Observe the signal status displayed on the interface to confirm whether the signal is normal.

5. XY Step Motor Test

Can be used to debug the position of XY axis clicks and switches.

6. Servo Test

This function is used to detect the spindle angle detection, ensuring that the spindle operates within a normal range.

7. Servo Angle Detection

Function Description: This function is used to detect the spindle operates within the normal range.

8. Continuous Run Detection

Function Description: Adjust the action interval time, the number of material-receiving origin detections, the number of cycles, etc.

9. Laser Offset

Function Description: Adjust the laser coordinates and needle coordinates, set the offset amount.

4.1 Led Detection

Click the [Port test] button in the menu to enter the test mode.

1、Click the "LCD Test" button.



2、Enter the screen test interface and select "Screen Test"



3、Set the screen test interval time.



4、Click "Stat test"



4.2 Panel Detection

Click the [Port Test] button in the menu to enter the test mode and proceed to the touchscreen test

<p>1、Click the "Touchscreen Test" button</p>	 <p>The screenshot shows the 'Database Setting' menu with a blue header. The 'Panel Detection' icon, which depicts a screen with a hand, is circled in red. Other icons include 'Laser Detector', 'Apex Detector', 'Output Detector', '3D step probe test', 'Servo test', 'Zero angle Contact test', 'Continuous Flaw Detection', 'Network setting', 'Analog gear set', and 'Inser offset'.</p>
<p>2、Press the Enter key to confirm</p>	 <p>The screenshot shows a warning dialog box with a yellow warning triangle icon and the text 'MES-P-273'. A green checkmark icon in the bottom right corner is circled in red. A red 'X' icon is in the bottom left corner.</p>
<p>3、Follow the cursor and click to calibrate step by step.</p>	 <p>The screenshot shows a black screen with a white crosshair in the top left corner, which is circled in red. Below the crosshair, the text 'Please click the corner on the touch screen for calibration' is visible.</p>
<p>4、Finally, return to the "Test Mode" interface.</p>	 <p>The screenshot shows the 'Database Setting' menu, identical to the first screenshot, with the 'Panel Detection' icon circled in red.</p>

4.3 Input Detection

Click the [input Signal Test] button to enter the input signal test interface. This allows you to click the communication control signals (ON/OFF). The interface includes the following content as shown in the figure below

Precautions

Before performing any operations, ensure that the mechanical device is correctly installed and connected to avoid errors caused by improper connections. During operation, pay attention to safety, avoid moving parts to prevent accidental injury.



4.4 Output Detection

Click the [Output Signal Test] button to enter the output signal test interface. This allows you to check the communication control signals (OFF/ON). The interface following content as shown in the figure below.

Precautions

Before performing any operations, ensure that the mechanical device is correctly installed and connected to avoid errors caused by improper connections. During operation, pay attention to safety, avoid moving parts to prevent accidental injury.



4.5 XY Step Motor Test



Click the XY stepper motor detection button to enter the XY stepper motor detection interface. On this interface, you can adjust the XY axis click position and switch.

4.6 Servo Test



Click the [Servo Motor Detection] button to enter the main spindle speed detection interface. in this interface, You can perform debugging of the main speed. As shown in the figure:

1. **Display Actual Speed:** Displays the current actual speed of the main spindle (RPM)
2. **Set Speed:** Allows input or button press to reach the target speed.
3. **Control Buttons:** Start, stop, reset, and other basic operation buttons.
4. **Alarm:** If the set safety range is exceeded, an alarm message will be displayed.
5. **Adjust and Optimize:** If adjustments to the main spindle speed are needed, you can reset the target value.

4.7 Servo Angle Detection



Click the [Main Spindle angle Detection] button to enter the main spindle motor installation angle calibrate interface. In this interface, you can perform spindle motor debugging. The interface is shown in the figure below.

1. Before adjustment, ensure necessary safety measures are taken. Install sensor correctly onto the main spindle and reference point, ensuring they are secure and positioned correctly. Open the interface and complete the initialization settings.
2. In the interface, locate the "Main Spindle Motor Release/Lock" button. Clicking this button allows the motor to be released or locked state, enabling free movement for adjustment.
3. Perform measurements by rotating the main spindle to a certain angle, read multiple positions to collect data, calibrate the current deviation, and display it on the interface.
4. After adjusting to the desired position, locate the "Main Spindle Motor Lock" button. After adjusting to the desired position, locate the "Main Spindle Motor Lock"
5. button in the software interface to prevent parameters are within the allowable tolerance range.
6. Final verification: Perform a complete measurement again to ensure all parameters are within the allowable tolerance range.

4.8 Continuous Run Detection



Click the 'Continuous Operation Detection' button to enter the continuous operation detection interface. Adjust the action interval time, the number of material receiving origin detections, the number of cycles, etc.

Chapter 5 System Upgrade and Function Settings

5.1 System Upgrade

Click the [System & Upgrade] button in the motor debugging interface ,then click the [Upgrade] button to enter the firmware version mode interface. This interface is used to view the version numbers of the control system,such as the main contrroller ,panel,manufacturer logo,and stepper motor versions.



1.Version Upgrade:Locate the upgrade file on the USB drive.The system will prompt you to install the update.Click the [One-Click Upgrade] button to start the upgrade process.Do not turn off the power during the upgrade.After the upgrade is complete,a prompt box will appear.Turn off and restart the power, then wait patiently.After restarting ,check if the new version functions properly to ensure everything is running smoothly.

2.Error Handling:If an upgrade occurs or you need to a previous version.click the top-left corner upon startup to enter the settings interface and modify the system version.If you encounter error messages,try restating the settings and performing the upgrade again.

3.System Restore:Click the[one-Click Restore] button to enter the system restore interface.You can restore interface.You can restore all parameters or select specific parameters to restore.The system will revert to the initial default settings.After restoration is complete,a prompt box will appear.Turn off and restart the power.

4.Troubleshooting:If the upgrade issue persists,contact the company's technical support team.Plese problem and any solutions you have already tried to help the technical support team.Please provide a detailed description of the problem and any solutions you have already tried to help the technicians understand the situation better and offer assistance.



5.2 Function Mode





Click on the [System and Upgrade] ->[Function Settings] button on the motor debugging interface to enter the function mode interface. This interface is divided into sixteen modules. As shown in the following figure.



Chapter 6 Reserved Para

6.1 Reserved Parameter Operation

Operation steps:

<p>1. Click on the menu.</p>	 <p>The screenshot shows the main control interface with a central display area and a bottom menu bar. The menu bar contains several icons, with the first icon (a square with a circle) circled in red.</p>
<p>2. Enter parameter settings.</p>	 <p>The screenshot shows a grid of parameter setting icons. The icon representing 'Reserved Para' (a gear with a lightning bolt) is circled in red. A red 'X' icon is visible in the bottom right corner.</p>
<p>3. Scroll to the last page and click on the reserved parameters.</p>	 <p>The screenshot shows a menu with several buttons: 'Edit', 'Reset set', 'Step adjustment', 'Reserved Para', 'Advanced para', 'Load set', 'Set language', and 'Reserved Para'. The 'Reserved Para' button at the bottom right is circled in red. Navigation arrows (left and right) are also circled in red. A red 'X' icon is in the bottom left corner.</p>
<p>4. Modify parameters.</p>	 <p>The screenshot shows the 'Reserved Para' screen with a list of parameters. The first parameter, 'Conversion rate 4 to 400Hz', has a value of '30' which is circled in red. Other parameters include 'Conversion rate 8 to 400Hz' (400), 'Conversion rate 16 to 400Hz' (1600), 'Conversion rate 32 to 400Hz' (350), 'Conversion rate 64 to 400Hz' (350), 'Conversion rate 128 to 400Hz' (280), and 'Conversion rate 256 to 400Hz' (180). A red 'X' icon is in the bottom left corner, and navigation arrows are at the bottom.</p>

6.2 Parameter Introduction

Reserved Parameters Page 1:



Serial Number	parameter	Default value	Modify the interval
1	External pressure frame drop delay	30	Range: 0-30000
2	External pressure frame drop lift delay	400	Range: 0-30000
3	internal pressure frame lifting delay	1600	Range: 0-30000
4	Inner pressure frame drop delay	350	Range: 0-30000
5	Lifting cylinder 1 cylinder extension delay time	350	Range: 0-30000
6	Lifting cylinder 1 cylinder retracting delay time	280	Range: 0-30000
7	Side sliding telescopic extension delay	150	Range: 0-30000

Reserved Parameters Page 2:



Serial Number	parameter	Default value	Modify the interval
1	Side slip retraction delay	100	Range: 0-30000
2	External pressure frame fixed material open delay	150	Range: 0-30000
3	External pressure frame fixed material closing delay	0	Range: 0-30000
4	The lifting delay of the discharging lifting plate 1	400	Range: 0-30000
5	Is the feeding and lifting plate used	Used	Used/Not used
6	Feeding tray rise and fall open delay	250	Range: 0-30000
7	Feeding tray rise and fall close delay	200	Range: 0-30000

Reserved Parameters Page 3:



Serial Number	parameter	Default value	Modify the interval
1	Delay after front and back fold knife is insert	170	Range: 0-30000
2	Delay after front and back fold knife is retracted	170	Range: 0-30000
3	Delay after front and back fold knives are lowered	160	Range: 0-30000
4	Delay after front and back fold knives rise	160	Range: 0-30000
5	Feeding tray clamp delay	250	Range: 0-30000
6	Feeding tray return delay	200	Range: 0-30000
7	Left and right folded material 1 sandwiched in delay	160	Range: 0-30000

Reserved Parameters Page 4:



Serial Number	parameter	Default value	Modify the interval
1	Left and right folding 1 return delay	160	Range: 0-30000
2	Left and right folding material 2 failing delay	160	Range: 0-30000
3	Left and right folding 2 rise delay	160	Range: 0-30000
4	Side sliding telescopic 2 extension delay	120	Range: 0-30000
5	Lifting and opening delay of bag cloth	600	Range: 0-30000
6	Side slip telescopic 2 descent delay	200	Range: 0-30000
7	Side sliding telescopic 2 lifting delay	30	Range: 0-30000

Reserved Parameters Page 5:



Serial Number	parameter	Default value	Modify the interval
1	Delay after the outer pressing frame returns to the reclaiming position	100	Range: 0-30000
2	X tray motor extension delay	200	Range: 0-30000
3	X tray motor retract delay	350	Range: 0-30000
4	Side-slip lift small cylinder fall delay	100	Range: 0-30000
5	Side-slip lift small cylinder lift delay	250	Range: 0-30000
6	No-pole motor length	2500	Range: 0-2500
7	X tray motor speed gear	5	Range: 0-9

Reserved Parameters Page 6:



Serial Number	Parameter	Default value	Modify the interval
1	How long does it take for the carrier to return to the pressure frame	400	Range: 0-30000 milliseconds
2	Y pallet motor gear	4	Range: 0-9
3	Y pallet motor speed	800	Range: 0-800
4	Y pallet in place safety length	700	Range: 0-2500
5	Whether the front and back fold knives are separated	Not separate	Separate/Not Separate
6	Outer frame manganese steel clip open delay	0	Range: 0-30000
7	Outer frame manganese steel clip close delay	150	Range: 0-30000

Reserved Parameters Page 7:



Serial Number	parameter	Default value	Modify the interval
1	Fixed material Open position	The splice point	The splice point(The splice point is open)/(star point)star point open
2	If use bag cloth function	No use	Use/No Use
3	Whether to shield bag folding action	Do not block	No Shielding/Shield
4	Stretch cylinder/small cylinder switch	close	Close/Open
5	Inter pressure frame Expansion and contraction/invalid	Valid	valid/invalid
6	Is the suction shut-off function used during secondary material retrieval	No use	Use/ no use
7	Folding knife motor whether used	No use	Use/ no use

Reserved Parameters Page 8:



Serial Number	parameter	Default value	Modify the interval
1	Bag cloth motor whether use	There is a pause	Not used/no pause/pauses
2	Laser lifting plate lifting time	300	Range: 0-9999
3	Laser lifting plate telescopic delay	300	Range: 0-9999
4	Reserved para	0	Range: 0-9999
5	Whether to use pallet receiving coordinates	Not used	Use/ not used
6	Y tray receipt motor length	3500	Range: 0-25000
7	Y tray rise and open delay	350	Range: 0-30000

Reserved Parameters Page 9:



Serial Number	parameter	Default value	Modify the interval
1	Y tray rise and close delay	200	Range: 0-30000
2	Y clamp tray open delay	200	Range: 0-30000
3	Y clamp tray close delay	100	Range: 0-30000
4	Tray fixed open delay	200	Range: 0-30000
5	Tray fixed close delay	200	Range: 0-30000
6	Y pallet reclaimer motor length	1900	Range: 0-25000
7	Lifting delay of external pressure frame	400	Range: 0-30000

Reserved Parameters Page 10:



Serial Number	parameter	Default value	Modify the interval
1	Y pallet arrival safety length delay	500	Range: 0-30000
2	Whether to automatically fold after cutting	Not auto	Automatic/Non Automatic
3	Whether to automatically fold after the second sewing work at the same time	Not same time	Not same time/at the same time
4	Is the pocket lip baffle effective	Self auto	Invalid/Self auto/vaild auto
5	Delay between the extension and descent of the bag lip baffle	800	Range: 0-3000 milliseconds
6	Is the left and right folding knives closed	no	yes/no
7	Delay between lifting and retracting the lip baffle	1	Range: 1-3000 milliseconds

Reserved Parameters Page 11:



Serial Number	parameter	Default value	Modify the interval
1	Delay after the bag lip baffle is retracted	1	Range: 0-30000
2	The time for it takes for the air suction to reopen after the bag eyebrows is extended	0	Range: 0-30000
3	Press foot rotation delay	0	Range: 0-30000
4	Is a steam lift motor device used	Not used	Range: 0-30000
5	Steam storage time	500	Use/ not used
6	Distance limit for up and down rotation patterns	220	Range: 0-30000
7	Side slip motion mode	Mode 1	Range: 0-30000

Reserved Parameters Page 12:



Serial Number	parameter	Default value	Modify the interval
1	Sewing mode	Auto mode	Auto mode/normal mode/Placket mode
2	Wire cutting and blowing cylinder	200	Range: 0-2000
3	Reserved para	0	Range: 0-9999